




PRESSURE/TORQUE CONVERSION CHART

PRESSURE IN PSI	FT. LBS.	N-m	5MD
1000	525	712	
1200	635	861	
1400	745	1010	
1600	845	1146	
1800	1000	1356	
2000	1060	1437	
2200	1165	1580	
2400	1270	1722	
2600	1395	1891	
2800	1505	2041	
3000	1600	2169	
3200	1715	2325	
3400	1825	2474	
3600	1935	2624	
3800	2050	2779	
4000	2170	2942	
4200	2270	3078	
4400	2380	3227	
4600	2490	3376	
4800	2615	3545	
5000	2735	3708	
5200	2840	3851	
5400	2950	4000	
5600	3060	4149	
5800	3175	4305	
6000	3285	4454	
6200	3395	4603	
6400	3515	4766	
6600	3620	4908	
6800	3740	5071	
7000	3840	5206	
7200	3955	5362	
7400	4065	5511	
7600	4175	5661	
7800	4285	5810	
8000	4400	5966	
8200	4495	6094	
8400	4610	6250	
8600	4725	6406	
8800	4820	6535	
9000	4935	6691	
9200	5050	6847	
9400	5145	6976	
9600	5265	7138	
9800	5380	7294	
10000	5480	7430	



For Reference Only